

Watering Hose Post for under \$20

It's the perfect time of year to get any of those outdoor projects that have been put off finally finished. For myself its sprucing up the front yard and there is endless amounts to do in the backyard. The one big thing my front yard needed is a spot to hang the watering hose. Its connection is in the garage, which is normally where the hose would be hung. However, it gets used so often that it never seems to make it back to the spot in the garage. So, the first outdoor project this year was the Watering Hose Post!

I decided to take some of the extra scrap pieces I had lying around and make a freestanding post for it and I'm pretty happy with the result. It adds some curb appeal while making it more functional. The hose is actually being hung up again.

Make sure you read through the instructions and look over the plans fully before you start your project. Check out the "Before You Start" page for more on tool information, tips & tricks. Always stay safe and wear all safety protection. It is always best to make your cuts as you go and as they say, measure twice and cut once.

If you have any questions just ask away!

Shopping List

- 1 – 4"x4"x8' Fence post
- 1 – Scrap Piece of 2"x6" x 6"
- 2 1/2" Screws – Pocket Screws if using Kreg Jig
- 1 – Basic Hose Hanger

Stain

Polyurethane

Cut List

Dimensions can change if you are looking to make the Post Taller

1 – 2" x 6" @ 5 1/2" – Top Piece

1 – 4" x 4" @ 3'

2 – 4" x 4" @ 8"

Tools Needed



Circular Saw



Drill



Kreg Jig



Tape Measure



Pencil



Safety Glasses



Ear Protection

Step-by-Step

After you have made all the necessary cuts for this build, we will start by making the base. If you have

Using the 3 pieces of 4" x 4" cut at 11", attach them together using pocket holes, or just screw in from an angle.

Next, we will attach the post to the base using the same method of using pocket holes.

Attach the top 2" x 6" piece to the top of the post by screwing directly from the top of the board. Another option, is you can buy one of the decorative fence post toppers to use

on top.

Now comes the time to stain and seal the wood and allow it to fully dry before you attach the Hose Hanger

Place it where you want and there you go!,



Now subscribe below to get instant emails to new posts & projects.

&

Check me out on [Pinterest](#) too!

DIY Workbench for Under \$70

A workbench is one of those “must-haves” when doing any sort of wood working. It does not have to be large, but you want to have enough space to do any clamping or sanding. The main key overall, is to have the bench be sturdy and functional.

For the longest time, my workbench consisted of an old bathroom cabinet and just had a piece of plywood for a top. It had worked for the time being, it was something at least. However, it wasn't very sturdy, nor was I able to clamp anything to it. I think the worst thing, that really drove me insane was the lack of organization with it. Everything in the cabinet was hard to find!

Finally, I started taking the steps to get the organization in the garage that I wanted! The first thing, taking a hammer and destroying the already falling apart vanity cabinet.

Slowly but surely I have been making the storage systems that I have wanted, most of it out of scrap wood. I'll do another post soon giving a tour of my workshop/garage, but for now

here is the How-to on a nice sturdy workbench. I made my bench 8' long, but feel free to downsize for your own needs! Always just make sure that the leg spread is as large as possible to get give the most solid frame.

This DIY Tutorial is based upon my second workbench. My first bench, is identical to this however the top is made of 2"x3"x8's instead, which weighs quite a bit more, and only costs slightly more. Both of my workbenches are 8' long, so just size and cut down yours according to what will be more functional for you.

Supplies Needed

6 – 2" x 4" x 8'
12 – 2" x 2" x 8'
8 – Hex Bolts
16- Washer
8 – Nuts
Wood Glue
Screws

Tools Needed



Drill & Screw Bit



Drill Bit – To drill the holes for the Lag Bolts



Clamps



Saw



Socket Set



Pliers



Measuring Tape



Pencil



Safety Glasses



Work Gloves

Step By Step How To

1. The first thing you are going to do is glue the 2x2s together and clamp them thus ensuring that I got a good adhesion and that the boards were as level and flush as they could be. If you don't have a flat table to do this on, clean off a large area of floor space and do it on there. I glued the boards together one at a time. This way is more time-consuming but ensures that straightest top. I allowed 20 minutes for each piece to have the glue to cure before I went

on to the next piece. The good thing about this is that you do not need to sit around twiddling your thumbs, you can prep and get the base ready while you are making the top.



2. Its time to get the legs ready. Figure out the height that you want your bench to be; For me it was 38". Plan accordingly to account for the thickness of your top. 2"x2" boards are actually 1.5" x 1.5" therefore my legs would have to be 36.5" to get me the 38" Height.

3. Measure and cut your 2x4s for the legs. You will need 2 pieces of 2"x4" for each leg.

4. Clamp the 2 cut boards together ensuring that they are flush on all sides. You are now going to drill your holes for the Hex Bolts. You want the Drill Bit you use to be just slightly larger then the hex bolt. Now measure out where you want to have the holes to be located. I placed them at 6" from the bottom and 9 inches from the top.

5. Once your holes are drilled you are going to unclamp the boards and put wood glue in between them. Put the boards back together and re-clamp, again ensuring that they are flush. Now you are going to put the Hex bolts in with making sure there is a washer on both sides against the 2"x4"s then tighten with the nuts.



6. Repeat steps 4 and 5 for each legs.

7. This is where we are going to use the extra 2x4s we have to attach the front legs together and the back set of legs together. I wanted an 6" overhang on the ends with my table so I cut my 2 boards down to 7'.

8. Laying the 2 front legs on the ground I screwed the 7' 2"x4" to them, then repeated the step with the back legs.



9. Now is the time to attach the front and back legs together. Your top should be 17.5" wide in total, and you do not want too much of an overhang in the front and the back.

Note: remember larger leg span means sturdier workbench. I decided that the total width should be 17" leaving a 1/4" overhang in the front and back. Measure and cut the piece out for this and screw it in.



10. You also need to put in a blocking piece just above the bottom Hex Bolts on the legs to give the legs support down there. This is where the left over cut pieces are going to come into play. With 17" total you need, minus the front & back trim and the legs thus leaving you with an 8" piece on either side. Screw and attach this board in, however you may need to counter sink it since you are going through 2 pieces of 2"x4"s (legs)

10. Here is the last step for preparing the base. You are going to be screwing the top to the base later, but you will need blocking pieces to do so. You need to measure out the distance between the front and back trim pieces and cut and screw the blocking about a 1/3 of the way in on either side. Small pieces needed at the ends as well. See photo.



11. You also need to put in a blocking piece just above the bottom Hex Bolts on the legs to give the legs support down there. Now, this is where the left over cut pieces are going to come into play. With 17" total you need to minus the front & back trim and the legs. This should leave you with an 8" piece on either side. Screw and attach this board in, however you may need to counter sink it since you are going through 2 pieces of 2"x4"s (legs)



12. Now that the base is ready to go, your top should be as well. Next, place the top on the base and measure to insure it is even on all sides.



13. From underneath you are going to screw the blocking to the top (**NOTE: remember to use screws that are only about 1.5", so**

you don't go through the top)

14. If you want you can give your workbench a light sanding to make sure there are no rough points, however it isn't needed.

– Michelle

Now Subscribe below to get instant updates on posts & projects!

&

Follow me on [Pinterest](#) too!